

SECU™ INSTALLATION GUIDE

The 10-Minute Perimeter Upgrade: No Electrician, No Excavation, No Problem.

With **SECU**, all you need is a hex key and 10 minutes.

STEP 1: Prep & Polish (3 Minutes)

You don't need a backhoe—just a cloth or towel.

- Simply wipe down your existing 6" steel bollards to ensure a clean, snug fit for the unit.
- **The Mess Factor:** Zero—no dust, no debris, and no site cleanup required.

STEP 2: Slide & Sit (2 Minutes)

The SECU unit is precision-engineered to slide directly over your existing post.

- It is designed for a "glove-fit" over standard bollards, requiring no adapters or heavy machinery.
- **The Mess Factor:** Zero—it is a silent installation that won't disrupt your neighbors or customers.

STEP 3: The Lockdown (4 Minutes)

Secure your investment with our specialized, tamper-resistant set screws at the top and base.

- This step ensures your lighting is wind-rated and "theft-deterrent".
- Leave a 1/4 " gap at the bottom to keep it out of puddles and to let moisture escape.
- **The Mess Factor:** Zero—it requires only the simple sound of a hand tool.

STEP 4: The Final Glow (1 Minute)

Activate the intelligent solar sensors and perform a quick quality check.

- There is no wiring to the grid and no need to wait weeks for an electrician to show up.
- **The Mess Factor:** Zero—just recycle the empty cardboard boxes, and you're done.

THE "PRO-RESULTS" GUARANTEE

When you finish, the only evidence of your work will be a place that looks 10x safer and 10x more modern. You won't leave holes in the ground or "Pardon our Mess" signs—just instant security.

"If you can slide a sleeve onto a coffee cup, you can install a SECU. It really is that simple."